




The Quickest Refund and Exchange Progress



Return Policy

We maintain a 30-day return policy, allowing you to return any products purchased on this website within the time frame. Please contact us within 30 days after receiving the product(s), and ensure that the product(s) are returned to us without undue delays.




Kindly ensure that the returned products are in their original condition when sending them back to us to prevent any possibility of rejection by the warehouse.



When the product is not defective, and the reason for return is based on personal subjective factors such as a change of mind or a sudden dislike, the responsibility for the shipping cost will be borne by the customer.

RETURN/DAMAGE CLAIM Progress




Attention Please

- 1) Avoid contact with hot objects, such as boiling water and electric irons, to prevent deformation and damage.
- 2) To avoid scratches, such as knives and scissors, prevent them from getting cut.
- 3) Avoid sunlight shining on it directly so as to prevent cover layer from changing color and aging earlier.
- 4) If you accidentally spill coffee on the sofa, Please do not bleach, wiping the surface of the artificial leather fabric sofa with the mixture of white vinegar and baking soda are recommend , using a dry cloth to wipe off the moisture on the surface .
- 5) Please note that the artificial leather sofa is not machine washable, as it is a kind of nano sealing glue technology.
- 6) If the sofa is smelling, please try to air it 24-48 hours and the smell will give away.
- 7) To avoid pilling or deformation of the fabric, do not use violent scrubbing or a brushes.
- 8) Please use the specified detergent to wipe and avoid using bleach or bleach containing chlorine prevent fading and aging of the fabric.

Warm tips: Material certified according to OEKO-TEX STANDARD 100 and ECO PASSPORT. Every Parts of the Fabrics has been tested for harmless for health.
Customer service: service@wyidaseat.com


Electric version




A




B



C







D



Assemble The Backrest

Align the tabs on the backrest with the tabs on the base, and then insert the backrest downward. When you hear a click, the insertion is complete.







How to use it?

During use, you can control the movement via the buttons on the control panel. Then adjust the angle for complete relaxation to your preferred position. You can charge your electronic devices via the USB(5V1A) and TYPE-C(5V1A) interfaces on the control panel.


Press the button to recline in your favorite position.




Press the button to retract



Electric Headrest Adjustment



Press the button to retract



How to lock the pedals?

Please turn off the pedal via the control button. Make sure the pedals are fully closed before standing up.

Attention!




Before assembly, make sure you have received all the parts.
After unpacking a new mattress, it can be deformed by pressure.
To restore its shape, gently knock and tap them with your hands.
Feel free to contact us for any questions.

WARNING!



Please note that the area under the chair is not a play area.
Make sure there are no obstacles, children or pets in the vicinity of the chair or the area below when the chair is in use.

Warning

Do not sit fully back or stand upside down after lifting the footrest.



Leave enough space between the chair and the wall before you lean back.





Do not move the chair when it is leaning back.

